



DN200 - 1200

Maintenance & Overhaul

ST.WGR600 SERVICE KIT

- (1)ST.BJ026 Port Screw
- (1)ST.BJ048M Visc Fluid, 6oz
- (1)ST.BJ062S Antiseize, 2g
- (1)ST.GP049 Grease Syringe
- (1)ST.TR200121 Shaft O-Ring
- (1)ST.WG008 Nut O-Ring
- (2)ST.WGR006 Shaft Seal – Outer
- (2) ST.WGR009 Bearing
- (2)ST.WGR010 Shaft Seal – Inner
- (2)ST.WGR011 Seal Spacer
- (2)ST.WGR050 O-Ring
- (6)ST.WHR030 Torx Screws

ST.WGR601 FLUID KIT

- (1)ST.WGR601 Fluid Service Kit
- (1)ST.BC410 Syringe
- (2)ST.BJ026 Port Screw
- (1)ST.BJ048M Visc Fluid, 6oz
- (3) VISC. FLUID OPTIONS AVAIL.

ST.WGR 602 HP SEAL KIT

- (1)ST.BJ062S Antiseize, 2g
- (2)ST.WGR052 HP Seal Wave Spring
- (1)ST.WGR058 HP Seal – Shaft
- (1)ST.WGR059 HP Seal – Nut
- (2)ST.WGR050 HP Seal O-Ring

ST.WGR610 OVERHAUL KIT

- (2)ST.BJ026 Port Screw
- (1)ST.BJ062S Antiseize, 2g
- (1)ST.GP025P2SS Front Jet Plug
- (1)ST.TR200121 Shaft O-Ring
- (1)ST.WG008 Nut O-Ring
- (1)ST.WG014 Bearing Wave Spring
- (2)ST.WGR006 Shaft Seal – Outer
- (2)ST.WGR009 Bearing
- (2)ST.WGR010 Shaft Seal – Inner
- (2)ST.WGR011 Seal Spacer
- (6)ST.WHR030 Torx Screws
- (1)ST.WGR048 Visc Fluid, 6oz

(2)ST.WGR052 HP Seal Wave Spring

- (1)ST.WGR058 HP Seal – Shaft
- (1)ST.WGR059 HP Seal – Nut
- (1)ST.WGR076 Weep Seal O-Ring
- (1)ST.WGR180 Torx L-Wrench
- (2)ST.WGR050 HP Seal O-Ring

ST.WGR612 TOOL KIT

- (1) ST.WGR180 Torx L-Wrench
- (1) ST.WGR181 Removal Press Tube
- (1) ST.WGR182 Installation Press Tube
- (1) ST.WGR183 Hex Tool
- (1) ST.WGR184 HP Seal Install Tool